HOME DECORATORS

collection

Artisan Dining Table w/leaf

HDC #:08069 MFG #:AT7092

Carton A

Parts Check List



① Top Frame - 1



③ Crossbar - 1



④ Middle Top Panel - 1

HOME DECORATORS

collection

Artisan Dining Table w/leaf

HDC #:08069 MFG #:AT7092

Carton B



(2) Side Frame - 2

HOME DECORATORS collection®

Artisan Dining Table w/leaf

Assembly Instructions

HDC #:08069 MFG #:AT7092

Please read over the instructions; it will be a time-saver in the long run.

Note: Before assembly, please be sure to work on a soft flat surface to avoid any damage to the finish.



Parts Check List

Please remove all the parts carefully from the box. Thoroughly clean all wood surfaces to remove dust and dirt that may have settled onto the finish.



① Top Frame - 1



② Side Frame - 2



③ Crossbar - 1



④ Middle Top Panel - 1

Hardware Check List

Please take all the hardware listed below out of the hardware bag.

A 

Cross Bolt - 4 (Ø5/16")

F

Allen Bolt - 4
(Ø5/16"×2-1/2"L)

B

Wood Dowel - 4
(Ø10×40mm)

G

Lock Washer - 8 (Ø5/16")

C

Glue - 1(10g)

H

Flat Washer - 8 (Ø5/16"×19D)

D 

Allen Wrench - 1

I 

Rectangle Decoration - 2

E

Allen Bolt - 8
(Ø5/16"×2"L)

J

Wood Dowel - 4
(Ø10×30mm)

1. Please take the apron frame off before assembly.
2. Fill the middle holes on both apron frame and Crossbar(3) with Glue(C) .Then insert Wood Dowels(B&J) .
   See figure below:



3. Attach Side Frame(2) to apron frame and Crossbar(3) with Allen Bolts(E&F) and Cross Bolts(A) through Lock Washers(G), Flat Washers(H) by Allen Wrench(D) .
4. Attach Rectangle Decoration(I) to Side Frame(2). See figure below:



5. Attach the base to the Top Frame(1) with bolts.
   See figure below:



6. Turn the table upright. Slide open the top frame and place the removable leaf(4) in the middle. Slide the sides into the place to secure the removable leaf(4).
   See figure below:



Assembly is now complete!